



ICP-OES measurement of some transition metals in HF acid media

Osváth, Szabolcs

Publication date:
2017

Document Version
Publisher's PDF, also known as Version of record

[Link back to DTU Orbit](#)

Citation (APA):
Osváth, S. (Author). (2017). ICP-OES measurement of some transition metals in HF acid media. Sound/Visual production (digital)

General rights

Copyright and moral rights for the publications made accessible in the public portal are retained by the authors and/or other copyright owners and it is a condition of accessing publications that users recognise and abide by the legal requirements associated with these rights.

- Users may download and print one copy of any publication from the public portal for the purpose of private study or research.
- You may not further distribute the material or use it for any profit-making activity or commercial gain
- You may freely distribute the URL identifying the publication in the public portal

If you believe that this document breaches copyright please contact us providing details, and we will remove access to the work immediately and investigate your claim.


ICP-OES measurement of some transition metals in HF acid media

Szabolcs Osváth

DTU Nutech

Risø Campus, Frederiksborgvej 399, 4000 Roskilde, Danmark

NKS-B ICP User Seminar (25-27 September 2017)



Introduction 1

- Method has to be developed for determination of ^{93}Mo , ^{94}Nb (and ^{93}Zr) from nuclear power plant wastes (for example steel samples).
- Many preliminary experiments for method developement have to be performed: a relatively fast and easy technique is needed to understand the chemical behavior of Mo and Nb (and Zr).
- Easy-to-measure isotopes (gamma-emitters): $^{95}\text{Zr} \rightarrow ^{95}\text{Nb}$
 - ^{95}Zr ($t_{1/2} = 64$ days): 724 keV (44%) and 756 keV (54%) gamma-line
 - ^{95}Nb ($t_{1/2} = 35$ days) : 765 keV (100%) gamma-line
 - No such isotope of Mo exists.
- No more working nuclear reactors at Risø! Without it the named radionuclides are very expensive to have (purchase).
- We have to rely on the stable isotopes of natural composition of these analytes. Their concentrations are measured using ICP-OES.
- Zr and Nb are „flourofil“ elements. [Anal Sci 25 (2009) 1181-1187]

[illegible]

Ca	Insoluble fluoride forming element
Na	Bare cation / Aquaphile elements

#: See text.

Introduction 2

- ^{94}Nb can be measured by gamma-spectrometry.
 - Radionuclides causing the Compton continuum have to be removed.
- ^{93}Mo can be measured by ICP-MS, LSC or X-ray spectrometry.
 - Each detection type needs a very pure source.
- A very effective method is needed. (Probably a several-steps method)
- Effectivity of each step has to be determined.
 - Decontamination factor (DF), separation factor
$$DF_{\text{component}} = A_{\text{component, before separation (step)}} / A_{\text{component, after separation (step)}}$$
$$DF_{\text{component}} = m_{\text{component, before separation (step)}} / m_{\text{component, after separation (step)}}$$
- To avoid the contamination of our laboratory, most preliminary experiments are performed using stable nuclides and ICP-OES as detection technique.

Equipment 1



Equipment 2

- Hardware: Varian Vista AX CCD Simultaneous ICP-AES
- Software: ICP Expert II (Agilent Vista PRO Instrument Software, version 2.0)
- Ca. 3 mL sample is needed (1 M alkali ... 1 M acid)
- Blank: 3% HNO₃
- The main difficulty:
 - HF acid is practically always needed when dissolving and separating Nb and Zr, so it is present in all of the samples to be measured.
 - However, HF damages the glassware of the ICP-OES equipment.
$$\text{SiO}_2 + 4 \text{ HF} \rightarrow \text{SiF}_4 + 2 \text{ H}_2\text{O}$$
- How to avoid this damage?
 - Dilution
 - Evaporation
 - Complexation

Dilution


- Authors of some papers (for example: Prog Nucl En 93 (2016) 362-370) do not take care of presence of F^- when its concentration is below 0.005 M.
- So dilution might be used in certain cases.
 - Typically when HF concentration is not much higher than the given level (for example: 0.01 M or 0.02 M).
- But dilution also decreases the concentration of the analytes, so it cannot be widely used.
 - "Official" limits of detection: Mo: 4 ppb = $\mu\text{g/L}$ = ng/mL
Nb: 4 ppb
Zr: 1.5 ppb

Evaporation

- Avoiding HF is practically impossible, as Zr and Nb can practically not be (and do not remain) dissolved without F^- . (Remember, they are “fluorophile” elements.)
- But the concentration of F^- can be decreased significantly.
- For example: in case of 10 mL ≥ 1 M HF (for example 2 M, 4 M, 6 M etc.)
 - evaporation
 - taking up in 100 μ L cc. HF + 100 μ l cc. HNO_3
 - dilution to 10 mL
 - Result: 0.28 M HF / 0.16 M HNO_3
- Don't forget to protect the glass window of your fume hood!

Complexation

- For complexation of excess F⁻, boric acid can be used (J Anal At Spectrom 11 (1996) 287-296):



- It has to be taken into account, that boric acid increases the number of false signals:
 - Mo: 201.512 nm line
 - Zr: 343.823 nm line
 - Fe: 234.830, 273.358 and 373.713 nm lines
 - Ni: 230.299 nm line
 - Mn: 344.199 nm line

Further difficulties 1

- "Real time" analysis is not possible; results are produced some days after the experiment.
 - Correction of experiment's parameters is mainly not possible.
 - A huge drawback compared to gamma-spectrometry.
- (But measurement of an individual sample is much faster.)

Further difficulties 2

- A very wide range of concentrations has to be managed.
 - Composition of NIST Standard Reference Material 123c Stainless Steel (AISI 348) - a test material:
 - mainly (68.52%) Fe,
 - 17.40% Cr,
 - 11.34% Ni,
 - 1.75% Mn,
 - 0.65% Nb,
 - 0.22% Mo,
 - 0.12% Co.
 - Fe/Mo ≈ 311
 - If Mo ≈ 4 ppb (LOD) \Rightarrow Fe ≈ 1400 ppb
 - If Mo ≈ 100 ppb \Rightarrow Fe ≈ 30000 ppb
- Samples can be diluted; but isolation or separation are not possible, as we want to characterize the separation steps!

Measurement of Mo by ICP-OES [ppb]

Tube	Sample Labels	Mo 201,512	Mo 202,032	Mo 203,846	Mo 204,598	Mo 281,615	Mo avg.	Mo std(s)														Real
1	Blank	0	0	0	0	0	0,0	0,0														
2	Standard 1	153	153	153	153	153	153,0	0,0														
3	Standard 2	765	765	765	765	765	765,0	0,0														
4	Standard 3	1530	1530	1530	1530	1530	1530,0	0,0														
5	Water	4,6777	9,04198	3,2856	3,44991	6,90859	5,5	2,5														
6	0,01/Std-3 1,5x	328,518	325	321,406	336,727	330,724	328,5	5,8	329	325	321	337	331	328								330
7	0,01/Std-3 +FeMnSr	217,545	270,03	342,122	283,395	682,736	359,2	186,2	218	270	342	283	683	359	-41%	-18%	6%	-17%	69%	9%		
8	0,01/Std-4 1,5x	675,89	669,122	670,966	680,944	660,39	671,5	7,7	676	669	671	681	660	671								660
9	0,01/Std-4 +FeMnSr	487,366	527,268	625,329	562,79	969,818	634,5	194,2	487	527	625	563	970	635	-32%	-24%	-7%	-19%	38%	-6%		
10	0,01/Std-5	1475	1519,79	1503,04	1501,32	1491,37	1498,1	16,5	1475	1520	1503	1501	1491	1498								1485
11	0,01/Std-5 +FeMnSr	893,052	913,341	1008,56	960,142	1267,81	1008,6	151,6	1161	1187	1311	1248	1648	1311	-24%	-25%	-14%	-18%	10%	-13%		
12	Water	5,40442	12,2196	5,68364	8,37302	7,36536	7,8	2,8														
13	0,50/S-3 1,5x	212,828	224,554	218,983	228,889	220,619	221,2	6,0	213	225	219	229	221	221								222
14	0,50/S-3 +FeMnSr	151,809	179,594	255,309	196,227	647,501	286,1	205,6	152	180	255	196	648	286	-33%	-22%	15%	-15%	98%	26%		
15	0,50/S-4 1,5x	435,827	441,378	438,954	444,3	438,808	439,9	3,2	436	441	439	444	439	440								444
16	0,50/S-4 +FeMnSr	307,817	348,675	428,102	358,454	757,646	440,1	182,7	308	349	428	358	758	440	-34%	-23%	-3%	-21%	53%	0%		
17	0,50/S-5	980,796	967,37	961,872	983,639	972,237	973,2	9,1	981	967	962	984	972	973								1000
18	0,50/S-5 +FeMnSr	526,26	578,333	679,08	615,579	1071,15	694,1	218,0	684	752	883	800	1392	902	-36%	-25%	-9%	-21%	36%	-8%		
19	Water	-4,46468	9,0319	9,62996	9,69169	7,84647	7,2	4,1														

Conclusions

- ICP technique can be used for development of a radioanalytical method (determination of recoveries of analytes and decontamination factors of disturbing components); but some strange or unusual difficulties can arise.

Thank you very much

for this challenging task, and
for your kind attention.



DTU Nutech
Center for Nukleare Teknologier

$$f(x+\Delta x) = \sum_{i=0}^{\infty} \frac{(\Delta x)^i}{i!} f^{(i)}(x) \quad \Delta \int_a^b \epsilon \Theta + \Omega \int \delta e^{i\pi} = \{2.7182818284\}$$

$$\infty \quad \chi^2 \quad \Sigma \quad ! \quad >$$